

Monteringsanvisning

OBS. Använd ej skruvdragare.

1. Sätt fast den undre sargen (3) i höger sida (2) genom att sätta i en plugg i det övre hålet på sargen och en sargsprint i hålet undertill, se bild.
2. Vrid sargsprinten så att gängorna kommer mitt för skruvhålet. Skruva fast med insexskruv och medföljande nyckel.
3. Skruva fast vänster sida (1) på samma vis.
4. Lägg hyllplanet (4) på plats, den raka kanten är bakkanten. Skruva fast hyllplanet underifrån med stjärnskruv.
5. Skruva sist fast rundstaven (5) högst upp med de återstående stjärnskruvarna.

Assembly manual

Do not use electric screwdrivers.

1. Attach the crossbar (3) to the right side (2) by placing a wooden dowel in the top hole on the crossbar and a cross nut in the hole underneath the crossbar, see picture.
2. Turn the cross nut until the threads line up with the screw hole. Tighten the screw with enclosed Allen key.
3. Attach the left side (1) in the same way.
4. Put the shelf (4) into place with the straight edge towards the back. Fix the shelf with pozidrive screws from underneath.
5. Finally screw the round rod (5) to the top of the side pieces with the remaining pozidrive screws.

